

Technical Bulletin - TAB Number: TB-00415-00-211020

Encrypted SD Card Storage feature

Date Issued: 2/11/20

Product	Product Code	Firmware
Illustra Flex Gen 2 Cameras	IFS03D1ICWTT	Illustra.SS004.01.09.01.0042 onwards
	IFS03D1OCWIT	
	IFS03XNANWTT	
	IFS03B1BNWIT	
	IFS03B1ONWIT	
	IFS03CFOCWST	
	IFS08D2ICWTT	
	IFS08D2OCWIT	
	IFS08XNANWTT	
	IFS08B2ONWITA	
	IFS02P6INWIT	
	IFS02P6ONWIT	
	IFS02P6ONWITA	
	IFS02P6ISWTT	
	IFS02P6ONWITB	
	IFS02P6INWITB	
	IFS02P6ISWTTB	
	IFS03B1ONWTTA	
	IFS02P6ONWTTA	
	IFS02P6ONWTTB	
IFS03D1OCWTTA		
IFS08D2ICWTTB		
IFS08D2OCWITB		
IFS08B2ONWITB		

Issue

Currently if an SD card is removed from a camera, the contents can be easily accessed if the SD card is mounted elsewhere. This could be a violation of local privacy laws.

Solution

Introduction of the Encrypted SD Card storage feature which offers encryption for the entire contents of their SD card. When SD card Encryption is enabled the contents of the SD Card will only be accessible through the Camera Web GUI, unless a Custom Password has been set which allows password protected access to the SD card when mounted elsewhere. Currently this mounting is only supported on Linux systems.


NOTE: The user can disable Encrypted SD Card storage to revert to being able to access the SD card via Windows based systems, without a Password.

Disabling SD card encryption is not recommended.

Note: *There are three procedures below, these vary depending on the firmware installed in the camera. Use the correct procedure that relates to the firmware in your camera.*

Cameras manufactured with firmware Illustra.SS004.01.09.01.0042 or later


1. Insert SD card into camera.
2. Log in to camera Web GUI and select **Setup** on the Web User Interface banner to display the setup menus.
3. Select **SD Card Management** from the **Edge Recording** menu.



The SD card will show as unmounted with encryption enabled.

Please note: Encryption is always enabled by default after the camera has been reset. The user may disable encryption mode but any change to the encryption status requires the SD card to be formatted.

4. Format the SD card by selecting 'Format' and select 'Mount' to mount the encrypted SD card.




Please note: SD card will fail to mount until it has been formatted.




The user now has the option to encrypt SD card with custom password.

Please Note: The Custom Password is only required when the SD card is accessed independently from the camera. It will not affect SD card functionality while it is being used by the camera.

5. Log in to camera Web GUI and select **SD Card Management** from the **Edge Recording** menu.
6. Select 'Encrypt SD card with custom password'
7. Enter the custom password into both password fields and select 'Save'.



Once the Custom Password has been set, it can be edited or cleared at any time in the **SD Card Management** tab under the **Edge Recording** menu.




Please note: The Custom Password will remain set after a firmware upgrade. The Custom Password will be cleared after a reset.

The SD Card Encryption can be disabled at any time by unticking 'Encrypt entire contents of SD card'. However any changes to the encryption status requires the SD card to be formatted.

Upgrading camera from firmware pre- Illustra.S004.01.09.01.0042

1. Select **Setup** on the Web User Interface banner to display the setup menus.
2. Select **Maintenance** from the **System**.
3. Click on the **Browse** button and navigate to the latest firmware.
4. Select the file and select **Open**.
5. Select **Upload**.
Wait for Firmware Upgrade process to complete.
6. Log in to camera Web GUI and select **SD Card Management** from the **Edge Recording** menu.
If SD card was inserted pre-upgrade, or is inserted after the camera firmware has been upgraded, SD card will show as mounted and encryption options will be disabled until the camera has been reset.



Please note: Encryption will remain disabled by default after upgrading from firmware pre - Illustra.S004.01.09.01.0042 until the user manually enables it, or resets the camera, after which it is enabled by default.

To enable Encryption:


- a) Log in to camera Web GUI and select **SD Card Management** from the **Edge Recording** menu.
- b) Select 'Encrypt entire contents of SD card.'

Please note: Changing the encryption option requires the SD card to be formatted, all previously recorded data will be lost.


- c) User now has the option to encrypt SD card with Custom Password.

Please Note: The Custom Password is only required when the SD card is accessed independently from the camera. It will not affect SD card functionality while it is being used by the camera.

- d) Log in to camera Web Gui and select **SD Card Management** from the **Edge Recording** menu.
- e) Select 'Encrypt SD card with Custom Password'
- f) Enter Custom Password into both password fields.



- g) Once the Custom Password has been set, it can be edited or cleared at any time in the **SD Card Management** tab under the **Edge Recording** menu.



Please note: The Custom Password will remain set after a firmware upgrade. The Custom Password will be cleared after a reset.

SD Card Encryption can be disabled at any time by unticking 'Encrypt entire contents of SD card'. However any changes to the encryption status will require the SD card to be formatted.

Resetting a camera running firmware Illustra.S004.01.09.01.0042 or later

Please note: SD card encryption is always enabled by default after a camera reset

1. Log in to camera Web Gui and select **Setup** on the Web User Interface banner to display the setup menus.
2. Select **Maintenance** from the **System** menu.
3. Select Reset and OK.
4. Wait for Reset process to complete.
5. Log in to camera Web Gui and run through initial setup.
6. Select **SD Card Management** from the **Edge Recording** menu.
 - If SD card Encryption was enabled before reset and the same HostID is used after reset, the SD card will show as mounted and Encryption will be enabled.
 - If SD card Encryption was enabled before reset and a different HostID is used, the SD card will show as unmounted and Encryption will be enabled. SD card will need to be formatted before it can be mounted by the camera.
 - If SD card Encryption was disabled before reset, the SD card will show as unmounted and Encryption will be enabled. SD card will need to be formatted before it can be mounted by the camera.

Contact Information

If you have any questions regarding these release notes, please contact Tyco Security Products Technical Services at:

Toll Free: 800-507-6268, Option 2

International: 561-912-6259, Option 2

Alternative Number: 800-392-2873

Fax: 450-444-2029

Hours: 08:00 – 20:00 EST

Email: adtechservices@tycoint.com

Website: www.illustracameras.com

In Europe, Middle East and Africa, contact Technical Support at:

Toll Free: 00 800 CALLTYCO or 00 800 2255 8926

Direct: +31 475 352 722

Hours: 8am – 6pm CET

Email: video-support@jci.com

Website: www.tycosecurityproduct.com

Website: www.tycosecurityproducts.com

Local Direct dial numbers:

UK	+44 (0) 330 7771 300	Bahrain	(0) 800 041 27
France	0800 90 79 72	Greece	00800 31 229 453
Spain	900 99 31 61	Russia	810 800 20 521 031
Germany	0800 1806 757	Turkey	00800 31 923 007
Italy	+39 02 3051 0112 or +39 02 8998 1845	United Arab Emirates	(0) 800 0310 7123
Belgium	0800 76 452	Israel	+972 (0) 77 220 1350
Ireland	180 094 3570	Nordic Countries	+45 4494 9001
S. Africa	(0) 10 100 3292	Qatar	(00) 800 100 841
Oman	(00) 800 743 64	Lebanon	01 426 801 first, then dial 855 234 3677
Egypt	(0) 800 000 9697	KSA	+966 (0) 800 850 0830

In Latin America and Caribbean, contact Technical Support at:

Southern Latin America

Contact: Cesar Cristal
Phone: +54-11-4711-8711
Cell: +54911-6452-7573
Email: cristal@tycoint.com

Brazil (South)

Contact: Dani Hissnauer Miguel
Phone: +55 (11) 2172 9224
Cell: +55 (11) 97663-2653
Email: danimiguel@tycoint.com

Brazil (North)

Contact: Wagner Soares
Phone: +55 (21) 2108-6016 x.250
Cell: +55 (21) 99153-3519
Email: wsoares@tycoint.com

Northern Latin America & Caribbean

Contact: Hildebrando Duran
Phone: +57-1638-6278
Cell: +57-317668-9590
Email: hiduran@tycoint.com

Mexico

Contact: Marco Antonio Salguero
Phone: +52-55-5488-8092
Cell: +52-55-1473-4946
Email: msalguero@tycoint.com

In Asia Pacific, contact Technical Support at:

Toll Free: 00 800 CALLTYCO or 00 800 2255 8926

China Direct: +86 21 6163 8644

China Hotline: 400 671 1528

India Direct: +91 80 4199 0994

Australia Toll Free: 1 800 580 946

New Zealand & Pacific Direct: +64 9942 4004

Hours: 9am – 6pm Monday to Friday, China local time

Email: video-support@jci.com

Hours: 9am – 7pm Monday to Friday, India local time

Hours: 8am – 6pm Monday to Friday, Australia local time

Information furnished by Tyco Security Products is believed to be accurate and reliable. However, no responsibility is assumed by Tyco Security Products for its use, nor any infringements of other rights of third parties which may result from its use. No license is granted by implications or otherwise under any patent rights of Tyco Security Products.